



JIB CRANE (Floor-Fixed/-Simple type)

JBC 1037KH ~ 1537KH


Air balancer is to be separately purchased





Fixed portion with floor anchor bolts (directly fixed to the floor with anchor bolts)

If the floor slab is stronger than specified, you will be able to freely install the crane at any place of the slab. (Installation is to be made by the user.)

Dimensions of floor fixture




Dimensions of the hook for attaching a hoist




As the central joint of the arm can be turned as in the above figure, you can secure and effective use of a wide range of working area. (on the assumption that there is no obstacle around)



Example of use



You can use this crane with ease, enhancing the working efficiency.



You can prepare for the work and jig by attaching an air balancer. Women can do it with ease.



SPECIFICATIONS • DIMENSIONS TABLE

(Unit:mm)

Item No.	Rated capacity (kg)	Lifting height (m)	S	A1	A2	A3	Weight (kg)	Remarks
JBC 1037KH	100	3.1	3,847	1,714	1,805	106	266	
JBC 1521KH	150		2,097	875	858	142	246	
JBC 1537KH			3,847	1,714	1,769	142	286	

Apart from the indicated specifications, we will provide custom-ordered products according to the user's needs. You will be separately charged for freight and installation.