

# ■ REPLACEMENT PARTS AND ASSEMBLIES

Part No.	Part Name	Item No.	Q'ty (pc)	Part No.	Part Name	Item No.	Q'ty (pc)
	Shackle	SLHH			Support Bolt/Nut (for Shackle)	SLHB	
1	Shackle		1	3	Support Bolt (for Shackle)		1
9	Swivel		1	4	Support Nut (for Shackle)		1
10	Steel Ball		10	5	Spring Pin (for Support Bolt)		1
11	Oil Seal		1	2	Lever	SLHL	1
12	Hex. Hole Button Bolt		1		Support Pin (for Lever)	SLHC	
13	Spring Washer		1	6	Support Pin (for Lever)		1
				7	Support Bolt		1
				8	Spring	SLHS	1

※ When ordering, specify the rated capacity (ton) and with “ASB”.  
 (Example: Lever for SLH3ASB is SLHL3ASB.)

