

## REPLACEMENT PARTS AND ASSEMBLIES

Part No.	Part Name	Item No.	Set Q'ty(pc)
Shackle Assembly		SCH	
5	Shackle	SCCH	1
6	Support Bolt (for Shackle)	SCCN	1
12	* Nut (for Shackle)		1
11	Cotter Pin (for Support Bolt)		1
Screw		SCR	
2	Screw	SCCR	1
7	Handle	SCCU	1
3	Cam	SCCT	1 set
10	Stop Ring		
Pad Assembly		SCP	
4	Pad	SCCP	1
8	Bolt (for Pad)	SCCV	1
9	Nylon Nut (for Pad)		1

- When ordering, specify the rated capacity (ton) of item No. (with "W" at the end in case of wide type)  
(Example : Screw for SCC3 is SCCR3)  
(Example : Cam for SCC1W is SCCT1W)
- Handle of SCC0.5 and SCC0.3W is ordered as an assembly, and the Assembly No. is SCR0.5 (0.3W).
- Periodic lubrication is required at a sliding portion of Cam and Screw (spherical portion).

