
■REPLACEMENT PARTS AND ASSEMBLIES



Part No.	Part Name	Item No.	Qty(pc)
1	Screw	SSCR130	1
2	Handle		1
3	Cam	SST130	1
4	Retaining Ring		2
5	Pad	—	1
6	Spring		1

※ Periodic lubrication is required at the spherical section of Cam and the sliding section of Screw.