


REPLACEMENT PARTS AND ASSEMBLIES

Part No.	Part Name	Item No.	Set Q'ty
Screw Assembly		SDCR	
1	Screw		1
2	Handle		1
Sleeve Assembly		SDS	
※ 9	Sleeve		1
※10	Hex. Hole Head Screw		2
Cam Assembly		SDT	
3	Circular Cam		1
5	Cam Holder		1
4	Stopper Pin		2
8	Steel Ball		1
7	Spring		1
6	Retaining Ring		1

Attention:

- 1)When ordering, specify the rated capacity (ton) of item No. with “N” or “WN”.
(Example: Screw for SDC3N is SDCR3N.)
(Example: Cam for SDC1.5WN is SDT1.5WN.)
- 2)Periodic lubrication is required at cam holder and screw.



※marked parts are used only for SDC5N.