

■ REPLACEMENT PARTS AND ASSEMBLIES

Part No.	Part Name	Item No.	Set Q'ty
	Screw Assembly	SDCR	
1	Screw		1
2	Handle		1
	Sleeve Assembly	SDCB	
3	Sleeve		1
4	Hex. Hole Head Screw		1
	Cam Assembly	SDT	
5	Circular Cam		1
7	Cam Holder		1
6	Stopper Pin		2
11	Collar		1
10	Guide Pin		1
9	Steel Ball		1
8	Spring		1
12	Disc Spring		5 (4 for SDC6.3S)
14	Spring Washer		1
13	Hex. Hole Head Bolt		1

Attention:

- 1) When ordering, specify the rated capacity (ton) of item No. with "S".
(Example: Screw assembly for SDC3.2S is SDCR3.2S.)
- 2) Periodic lubrication is required at cam holder and screw.

